


JP01

Thermostatic Handle and Diverter Designer: John Pawson



COCOON


Dimensioned drawing



Spare Parts List

JP 01 therm/div-valve

Part no	Spare part code	Article No	Description	QTY
1.	JP01THERM/DIV-EXT-001	JP01THERM/DIV-EXT-001.000	Lever handle	1
2.	JP01THERM/DIV-EXT-002	JP01THERM/DIV-EXT-002.000	Pin M5	1
3.	JP01THERM/DIV-EXT-003	JP01THERM/DIV-EXT-003.000	Collar Ø66mm	1
4.	JP01THERM/DIV-EXT-004	70NBR103F	O ring Ø43 X 2	1
5.	JP01THERM/DIV-EXT-005	70NBR103F	O ring Ø57 X 2	1
6.	JP01THERM/DIV-EXT-006	JP01THERM/DIV-EXT-006.000	Sleeve ring	1
7.	JP01THERM/DIV-EXT-007	JP01THERM/DIV-EXT-007.000	Lever handle	1
8.	JP01THERM/DIV-EXT-008	JP01THERM/DIV-EXT-008.000	Pin M5	1
9.	JP01THERM/DIV-EXT-009	JP01THERM/DIV-EXT-009.000	Temp. safety button	1
10.	JP01THERM/DIV-EXT-010	JP01THERM/DIV-EXT-010.000	Spring	1
11.	JP01THERM/DIV-EXT-011	JP01THERM/DIV-EXT-011.000	Pin M5	1
12.	JP01THERM/DIV-EXT-012	JP01THERM/DIV-EXT-012.000	Collar Ø44m	1
13.	JP01THERM/DIV-EXT-013	JP01THERM/DIV-EXT-013.000	Plastic snap insert	1
14.	JP01THERM/DIV-EXT-014	JP01THERM/DIV-EXT-014.000	Screw	1
15.	JP01THERM/DIV-EXT-015	JP01THERM/DIV-EXT-015.000	Collar Ø66mm	1
16.	JP01THERM/DIV-EXT-016	70NBR103F	O ring Ø43 X 2	1
17.	JP01THERM/DIV-EXT-017	70NBR103F	O ring Ø57 X 2	1
18.	JP01THERM/DIV-EXT-018	JP01THERM/DIV-EXT-018.000	Sleeve ring	1



Installation Manual

JP-01-THERM/DIV-EXT

The pipes have to be rinsed before installation to avoid the pressure differences.

